

Do's and Don'ts – Cold Aisle Containment (CAC)

Do's and Don'ts of CAC

Do's....

- CAC Door to Be slide Opened and will automatically Close.
- CAC Polycarbonate sheet / Multiwall Sheet to be Wiped with a Lint Free Cloth.
- All components of CAC & it's Multiwall & Polycarbonate Sheets to be handled with Gloves.
- No Sharp Objects to touched to Sheets and Metal To avoid Scratches.
- Safety gears to be worn while carrying out HAC Related Work
- Ensure workers can get safely to and from where they work at height
- Ensure equipment is suitable, stable and strong enough for the job, maintained and checked regularly
- Take precautions when working on or near fragile surfaces
- Provide protection from falling objects
- Consider emergency evacuation and rescue procedures.
- Make use of required and necessary ladders, helmet and all necessary PPE kit.

Don't...

- CAC Door not to be Pulled or Pushed for Sliding Doors
- CAC Polycarbonate sheet / Multiwall sheets not to be Cleaned with Water or any Liquid to Avoid Scratches
- No External Loads to be Put on the Hot aisle Containment.
- Do not step on Polycarbonate / Multiwall sheets.
- Avoid Scratching of Polycarbonate sheets for Doors.
- Overload ladders – consider the equipment or materials workers are carrying before working at height. Check the pictogram or label on the ladder for information
- Overreach on ladders or stepladders
- Rest a ladder against weak upper surfaces, eg glazing or plastic gutters
- Use ladders or stepladders for strenuous or heavy tasks, only use them for light work of short duration (a maximum of 30 minutes at a time)
- Let anyone who is not competent (who doesn't have the skills, knowledge and experience to do the job) work at height.